

GEN 2.4 LOCATION INDICATORS

1. ENCODE		2. DECODE	
Location	Indicator	Indicator	Location
ANURADHAPURA	VCCA*	VCBI	KATUNAYAKE / Bandaranaike Intl. Airport Colombo
BATTICALOA	VCCB*	VCCA*	ANURADHAPURA
COLOMBO FIR	VCCF	VCCB*	BATTICALOA
GAL-OYA / Amparai	VCCG*	VCCC	RATMALANA/Colombo Intl. Airport Ratmalana
HINGURAKGODA / Minneriya	VCCH*	VCCF	COLOMBO FIR
IRANAMADU	VCCI*	VCCG*	GAL-OYA / Amparai
KANKESANTURAI / Jaffna Intl. Airport	VCCJ	VCCH*	HINGURAKGODA / Minneriya
KATUKURUNDA (NAGODA)	VCCN*	VCCI*	IRANAMADU
KATUNAYAKE/Bandaranaike Intl. Airport Colombo	VCBI	VCCJ	KANKESANTURAI / Jaffna Intl. Airport
KOGGALA	VCCK	VCCK	KOGGALA
MATTALA /Mattala Rajapaksa International Airport	VCRI	VCCN	KATUKURUNDA (NAGODA)
RATMALANA/Colombo Intl. Aiport Ratmalana	VCCC	VCCS*	SIGIRIYA
SIGIRIYA	VCCS*	VCCT	TRINCOMALEE/China Bay
TRINCOMALEE/China Bay	VCCT	VCCV*	VAVUNIYA
VAVUNIYA	VCCV*	VCCW*	WIRAWILA
WIRAWILA	VCCW*	VCRI	MATTALA /Mattala Rajapaksa International Airport.

* Location Indicators marked by an asterisk cannot be used in the address component of messages transmitted over the AFS.