

AERODROME CHART -ICAO

07° 10' 49" N  
079° 53' 07" E

ELEV 9m

TWR 118.7  
SMC 121.9

KATUNAYAKE/BANDARANAIKE INTL.  
AIRPORT COLOMBO

RWY	DIRECTION	THR	BEARING STRENGTH
04	40°	07° 10' 09.08"N 079° 52' 28.51"E	PCN85/F/B/X/T
22	220°	07° 11' 35.68"N 079° 53' 34.87"E	
APRONS			Ref. VCBI AD 2-37 to 39

